

Seem® 2 LED Perimeter


 $FSM2L_FL2$



⚠ MUST BE INSTALLED PRIOR TO DRYWALL /HARD CEILING ⚠ READ ALL INSTALLATION INSTRUCTIONS BEFORE BEGINNING INSTALLATION








BASIC INSTALLATION STEPS 1-13

SLIDING SLEEVES SEE PG 3 CORNERS SEE PG 4




FOCAL POINT RECOMMENDS STARTING WITH CORNER INSTALLATION IF APPLICABLE

SLIDING SLEEVE PAIRS (SSB) START & END WITH A SLIDING SLEEVE






GRID





DRYWALL/HARD CEILING








3

















MAKE ELECTRICAL CONNECTIONS

REPEAT STEPS 2 - 9 FOR EACH HOUSING SECTION







EMERGENCY



SEE BATTERY MANUFACTURER INSTRUCTIONS

EMERGENCY MAXIMUM MOUNTING HEIGHT: 19.00'

SLIDING SLEEVES



MAX LENGTH 12" PER SLEEVE




SLIDING SLEEVES & CORNERS DO NOT INTEGRATE

SINGLE SLIDING SLEEVE (SS):

EXAMPLE:


21' RUN LENGTH - 20' HOUSING = 12" SLIDING SLEEVE





SLIDING SLEEVE PAIR (SSB):


EXAMPLE:


(21' RUN LENGTH - 20' HOUSING) / 2 = 6" SLIDING SLEEVE ON EACH END


























CORNERS








































DRIVER SERVICE





Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.