seem® 4-LP







A

CONFIGURATIONS ARE RUN SPECIFIC, PLEASE CONSULT FACTORY DRAWINGS BEFORE BEGINNING INSTALLATION.





PARTS LISTS



KEY



POWER OFF




POWER ON





ATTENTION




GRID MOUNT ONLY SPACING FOR ALL GRID TYPES












Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).


To prevent electrical shock, disconnect electrical supply before installation or servicing.

















DRIVER SERVICE 1 ABOVE CEILING ACCESS ONLY

EMERGENCY



SEE BATTERY MANUFACTURER INSTRUCTIONS


EMERGENCY MAXIMUM MOUNTING HEIGHT: 19.00^{\prime}


Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).


To prevent electrical shock, disconnect electrical supply before installation or servicing.





ACUITY nLIGHT











CONNECT CAT-5 CABLE

Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.