

Patient Reading Companion


FRCL



FOCAL POINT™

⚠️ AVOID ALL CONTACT WITH LED SURFACE, LEDs ARE EASILY DAMAGED!

FOCAL POINT



KEY



POWER OFF



POWER ON




ATTENTION




ADDITIONAL INSTRUCTIONS

GRID INSTALLATION


1




2



3




4




BEAM ADJUSTMENT (NO TOOLS REQUIRED)

1



180° ROTATION

2



0-30° TILT


Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.

DRYWALL INSTALLATION

1




FOLLOW FOCAL POINT
INSTRUCTIONS FOR
FRAME KIT ASSEMBLY.
SEE IS0351



CUT OUT DIMENSIONS:


| | | |
|-----|------|---------|
| 8": | MIN: | 8.326" |
| | MAX: | 8.639" |
| 2': | MIN: | 24.250" |
| | MAX: | 24.563" |

2




MAKE ELECTRICAL CONNECTIONS

3




DRIVER SERVICE


1



2




3



LED MODULE SERVICE

1



⚠ AVOID ALL CONTACT WITH LED SURFACE,
LEDs ARE EASILY DAMAGED!

Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.