

Patient Reading Companion


FRCL



FOCAL POINT®

⚠️ AVOID ALL CONTACT WITH LED SURFACE, LEDs ARE EASILY DAMAGED!

FOCAL POINT



KEY



POWER OFF



POWER ON




ATTENTION




ADDITIONAL INSTRUCTIONS

GRID INSTALLATION


1




2



3




4



MAKE ELECTRICAL CONNECTIONS


BEAM ADJUSTMENT (NO TOOLS REQUIRED)

1



180° ROTATION

2



0-30° TILT


Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).
To prevent electrical shock, disconnect electrical supply before installation or servicing.

DRYWALL INSTALLATION

1




FOLLOW FOCAL POINT
INSTRUCTIONS FOR
FRAME KIT ASSEMBLY.
SEE IS0351



CUT OUT DIMENSIONS:


8":	MIN:	8.326"
	MAX:	8.639"
2':	MIN:	24.250"
	MAX:	24.563"

2




MAKE ELECTRICAL CONNECTIONS

3




DRIVER SERVICE


1



2




3



LED MODULE SERVICE

1



⚠ AVOID ALL CONTACT WITH LED SURFACE,
LEDs ARE EASILY DAMAGED!

Contractor is responsible for adequately reinforcing walls and/or ceilings to support luminaire weight. Focal Point, LLC accepts no responsibility for inadequately reinforced walls and/or ceilings. The information contained in this drawing is the sole property of Focal Point, LLC. Any reproduction in part or whole without the written permission of Focal Point, LLC is prohibited.