


# seem 4™ grid ceiling

FSM4





**! CONFIGURATIONS ARE RUN SPECIFIC, PLEASE CONSULT FACTORY DRAWINGS BEFORE BEGINNING INSTALLATION. !**




## FOCAL POINT



## PARTS LISTS




## KEY




## RAIL & CLIP GUIDE




CHECK RAIL & CLIP POSITIONS BEFORE INSTALLATION. ARROWS INDICATE SCREW POSITIONS. TO CHANGE IN THE FIELD REMOVE AND REINSTALL ACCORDING TO DIAGRAMS BELOW.




G1: STD 15/16" LAY-IN TILE  
G2: STD 9/16" LAY-IN TILE



G4: TALL 15/16" LAY-IN TILE  
G5: TALL 9/16" LAY-IN TILE



G3: 9/16" SLOT-TEE TEGULAR TILE  
T1: STD 15/16" TEGULAR TILE  
T2: STD 9/16" TEGULAR TILE  
T6: 9/16" NODE TEGULAR TILE













T4: TALL 15/16" TEGULAR TILE







STD = 1-1/2" TEE HEIGHT, TALL = 1-11/16" TEE HEIGHT

Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).  
To prevent electrical shock, disconnect electrical supply before installation or servicing.



Luminaires must be installed by a qualified electrician (check with local and national codes for proper installation).  
To prevent electrical shock, disconnect electrical supply before installation or servicing.



## BALLAST SERVICE

